

Dex-O-Tex Industrial Cheminert is a nonabsorbent, monolithic, resin cured system finished with a pigmented two-component topcoat. It has met the requirements of laboratory, kitchen, restroom and veterinary flooring needs. With proper care, this Cheminert floor will maintain its serviceability for many years.

Cleaning

Semi-clean room areas such as analytical laboratories are easily cleaned with a liquid detergent-water solution by mopping the floor, followed by a clean water rinse. Machine scrubbing is not usually necessary for these areas.

Maintenance

With the exception of Gloss Topcoat, the newly applied Cheminert Topcoat will exhibit an oily feeling surface. This is normal and is created during cure. It will be removed by the initial cleaning. It is best to delay this initial cleaning until the surface is at least four days old.

Kitchens or areas where oils and grease are present require more frequent cleaning in order to maintain slip retardance and appearance. An alkaline detergent, liquid or dry, mixed in water should be used. The solution should be spread on the surface, allowed to work approximately five minutes and scrubbed by a bristle brush mounted on a floor scrubbing machine. Cleaning cycles depend upon the amount of use the kitchen receives. Except for temporary maintenance, mopping will usually give unsatisfactory results for kitchens. This is especially true where DEX-O-TEX NS textures are present.

Common Problems to Avoid

If known staining agents, such as Methylene Blue, Iodine, or Gentian Violet, are present prompt clean up is recommended in order to maintain an unstained surface. It is also recommended that abrasive cleaners, bleach, ceramic tile cleaners, acidic detergents, de-scaling (for removing hard water stains) and solvent de-greasers not to be used on Cheminert surfaces. Though these compounds will not harm the functionality of the floor, visual appearance may be affected. Maintenance personnel using germicidal disinfectants should strictly follow the manufacturer's recommended dilutions.



DEX-O-TEX PRODUCT LINE Crossfield Products Corp.

West Coast Office
3000 E. Harcourt Street
Rancho Dominguez, CA
90221
310-886-9100
310-886-9119 fax

East Coast Office
140 Valley Road
Roselle Park, NJ
07204
908-245-2800
908-245-0659 fax

www.dexotex.com