

Chemical Resistance

Products →	Dex-O-thane CRU Matte			Quik-glaze			Quik-Glaze FC			Aeroflor 100			Posi-Tred Cr		
	1hr	24hrs	7d	1hr	24hrs	7d	1hr	24hrs	7d	1hr	24hrs	7d	1hr	24hrs	7d
CIP 100 soln (1oz/gal)	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
CIP 100 Concentrated	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Yellow	Yellow
CIP 200 soln (1oz/gal)	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Yellow
CIP 200 Concentrated	Green	Green	Green	Green	Green	Yellow	Green	Green	Yellow	Green	Orange	Red	Orange	Orange	Orange
CIP 220 soln (1oz/gal)	Green	Green	Green	Green	Green	Green	Green	Green	Yellow	Green	Green	Green	Green	Green	Green
CIP 220 Concentrated	Green	Yellow	Orange	Green	Green	Yellow	Green	Green	Yellow	Green	Yellow	Red	Orange	Red	Red
Vesphene soln (1oz/gal)	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
Vesphene	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
LPHsE soln (1/2 oz/gal)	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
LPHsE	Green	Yellow	Orange	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Orange	Red	Green	Green	Green
Sporklenz soln (1%)	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
IPA 70%	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green
Acidulate 45T	Green	Green	Green	Green	Green	Green	Green	Green	Green	Yellow	Orange	Red	Green	Yellow	Yellow
VHP	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green	Green



All testing was done in accordance with ASTM D1308 at 75°F and 50% RH. For further testing and results, please contact your local Dex-O-Tex Representative.